



TM



**T.E.T.® THESE = THOSE**

# # 18 Defoamer

**DATA SHEET**

**PRODUCT DESCRIPTION:**

An ultra concentrated foam eliminator for carpet extraction and automatic scrubber recovery tanks. Provides simple easy mixing that is mobile and requires no additional equipment. The specially engineered T.E.T.® bottle easily allows accurate dilution of the concentrate and assures the correct use solution. **Defoamer** eliminates foam in recovery tanks and works in hot or cool systems.

**FEATURES:**

**Saves Labor and Protects Equipment:**

Eliminates frequent trips to dump the recovery tank. Protects the vacuum motor from moisture damage.

**Safety:**

The special bottle prevents misuse of the product and protects the user and the carpet.

**Cost Effective:**

Ultra concentrated, one 16 ounce bottle provides foam relief for 128 gallons of recovery tank solution (16/8 gallon tanks). Controls end use cost while providing effective cleaning.

**PRODUCT SPECIFICATIONS:**

pH .....	7.1 ± 0.5
Appearance .....	White Emulsion, Liquid
Fragrance .....	None
Freezing Point .....	About 32°F
Solubility in Water .....	Complete
Flash Point .....	None

**INGREDIENTS:**

Water .....	7732-18-5
Polydimethylsiloxane .....	67762-90-7

**ECOLOGICAL INFORMATION**

- Contains no Phosphorus
- Concentrated; eliminates waste and provides source reduction.

DILUTIONS	HEALTH	FLAMMABILITY	REACTIVITY
CONCENTRATE	NFPA 0 HMIS	NFPA 0 HMIS	NFPA 0 HMIS
CONCENTRATED	NFPA 0 HMIS	NFPA 0 HMIS	NFPA 0 HMIS

0	1	2	3	4
Minimal	Slight	Moderate	Serious	Severe
Minimo	Minimo	Moderar	Grave	Drastico

# T.E.T.® #18 Defoamer

ELIMINATES FOAM IN RECOVERY TANKS

## USE INFORMATION

*Never use a defoamer in the cleaning solution tank.*

# DIRECTIONS

### DIRECTIONS



1. REMOVE CAP

2. SQUEEZE

3. POUR

### DIRECTIONS

1. **REMOVE CAP** and seal.
2. **SQUEEZE BOTTLE** and fill the portion control cup. Excess defoamer will automatically flow back into the bottle.
3. **POUR** the contents of the cup into the extractor recovery tank or into the automatic scrubber recovery tank. Be sure that the recovery tank solution comes in contact with the defoamer concentrate.

#### WARNING

May cause mild eye and skin irritation.

#### Prevention

Observe good industrial hygiene practices.

#### Response

Wash hands after handling.

#### Storage

Store away from incompatible materials.

#### Disposal

Dispose of waste and residues in accordance with local authority requirements.

#### PERSONAL PROTECTION:

**Respiratory Protection:** Not needed under normal conditions.

**Ventilation:** Use with adequate ventilation.

**Eye Protection:** Safety glasses are optional.

**Protective Gloves:** Protective gloves are optional.

**Other Protective Clothing or Equipment:** Wear clothing as necessary to prevent skin contact.

#### TRANSPORTATION

#### INFORMATION:

**U.S. DOT - Proper Shipping Name:** Not regulated by DOT.

**Marine Pollutant:** No

#### Franklin Cleaning Technology

One Fuller Way

Great Bend, KS 67530

United States

CHEMTREC (800) 424-9300

Emergency (620) 792-1711

24 hour Emergency (800) 424-9300

www.fullercommercial.com

F378016TDS-0315